



Product Appearance




- ① Quick Release Mounting Point ② Angle Adjustment Knob
③ Button ④ 1/4" Mounting Point

How to Use

1. Align the mounting point, then press onto metal groove at the bottom of the camera. Press firmly until you hear a clear click. Gently pull away from the camera to make sure it is attached and properly installed.



2. Move the angle adjustment knob upwards, then hold. Rotate the 1/4" mounting point to adjust the camera to your desired angle.



3. The 1/4" to Quick Release Adapter has a 1/4" mounting point to connect to other accessories, such as a selfie stick.

4. To uninstall, press and hold the two buttons on adapter to detach your camera.



Notes

- The product contains magnets. Keep it away from pacemakers and other devices to avoid interference.
- Keep the rotating part of the adapter clean. If any debris gets in, clean it before adjusting the angle to prevent disruption.
- When using, avoid dropping the product and do not use it in scenarios that may cause high-intensity impacts.
- This product is suitable for multiple Insta360 cameras, including Insta360 Ace Pro 2. Compatible models are regularly updated. Please check the latest compatible products on our official store.


Disclaimer

By using this product, you acknowledge and agree to this disclaimer. Inspect the product before each use, and do not use it if damaged. Except for defects covered by applicable law, you are solely responsible for your actions and any consequences arising from the use of this product. To the extent permitted by law, Insta360 reserves the right to interpret and amend this disclaimer.

After-Sales Service

The warranty period of the attached product is 3 months from the original retail purchase. Warranty service may vary according to the applicable laws of your state or jurisdiction. For detailed warranty policies, please visit <https://www.insta360.com/support/aftersales?name=repair>


产品外观




- ① 快拆接口 ② 角度调节推钮 ③ 按钮 ④ 1/4" 螺纹接口

如何使用

1. 按图示方向，将快拆接口对准并吸附至相机底部的金属槽，用力按压，直至听到一声清脆的“咔哒”声。用手拉动 1/4" 转快拆接口与相机，确保它们之间没有晃动或脱落，说明安装成功。



2. 向上拨动并按住角度调节推钮，此时可根据拍摄需求转动底部接口以调整相机角度。



3. 1/4" 转快拆接口可通过底部的 1/4" 螺纹接口外接自拍杆等其他配件。

4. 拆卸时，同时按住 1/4" 转快拆接口两侧的按钮，即可取下相机。



注意

- 本产品含磁铁，请远离心脏起搏器等易受干扰设备。
- 保持 1/4" 转快拆接口转动处清洁。若有异物进入，先清理干净后再调节角度，以免影响转动顺滑度。
- 使用时请避免产品跌落，且勿在可能产生高强度冲击的场景下使用。
- 本产品适用于影石 Insta360 Ace Pro 2 等多款影石相机产品。适配机型持续更新，请在官方商城查询最新适配产品。


免责声明

使用本产品即视为同意本声明。每次使用前请检查，破损请勿使用。除经依法认定的产品质量问题外，使用者应自行承担因使用行为及其后果产生的责任。在国家法律法规范围内，影石 Insta360 保留本声明的解释及修改权。

售后服务

自您最初零售购入之日起，本产品的保修期为 3 个月，不同国家和地区可能有所差异，请访问我们官网 <https://www.insta360.com/support/aftersales?name=repair> 了解您当地的详细售后服务流程和具体的保修条款，全面了解您的保修权益。


製品外観




- ① クイックリリースマウントポイント ② 角度調整ノブ
③ ボタン ④ 1/4" インチマウント

使用方法

1. 取り付け位置を合わせ、カメラ底部の金属溝に押し込みます。カチッという音がするまでしっかり押し込んでください。カメラから軽く引いて、しっかり取り付けられていることを確認してください。



2. 角度調整ノブを上動かして保持します。1/4 インチマウントを回転させ、カメラをお好みの角度に調整します。



3. 1/4" インチ クイックリリースアダプターには 1/4 イン

チマウントがあり、自撮り棒などのアクセサリに接続できます。

4. 取り外す際は、アダプターの 2 つのボタンを長押ししてカメラを取り外してください。



注意

- 本製品には磁石が含まれています。ペースメーカーなど、干渉を受ける可能性のある機器から離して使用してください。
- アダプターの回転部分は清潔に保ってください。異物が入った場合は、角度を調整する前に清掃し、動作不良を防いでください。
- 使用時は、製品を落としたり、強い衝撃が加わる可能性のある状況で使用したりしないでください。
- 本製品は Insta360 Ace Pro 2 を含む、複数の Insta360 カメラに対応しています。対応機種は随時更新されます。最新の対応製品は公式ストアでご確認ください。

免責事項

本製品を使用することにより、お客様は本免責事項に同意したものとみなされます。使用前に製品を確認し、損傷がある場合は使用しないでください。適用される法律で定められた欠陥を除き、本製品の使用に起因するお客様の行為および結果について単独で責任を負います。法の範囲内で、Insta360 は本免責事項の解釈および改訂の権利を留保します。

アフターサービス

本製品の保証期間は購入から 3 ヶ月です。保証サービスはお客様の国または司法管轄区域によって異なります。保証規定の詳細につきましては、下記をご覧ください
<https://insta360.com/support/aftersales?name=repair>

Insta360

1/4" to Quick Release Adapter

1/4" 转快拆接口

Instructions for Use

使用说明

取扱説明

Arashi Vision Inc. 影石创新科技股份有限公司 影石创新科技股份有限公司

Arashi Vision US LLC dba Insta360

TEL: +1 800 692 0360

WEB: www.insta360.com

EMAIL: service@insta360.com

ADDRESS: 7545 Irvine Center Drive, Suite 200, Irvine, CA 92618

Insta360 GmbH

TEL: +49 30 330 81669



WEB: www.insta360.com

EMAIL: service@insta360.com

ADDRESS: Emmy-Noether-Ring 4, 85716 Unterschleißheim Germany



V1.0

RACCOLTA
CARTA



305010100473